
Hydrotech 765 Valve Carbon Filter Quick Set Up Manual


Step 1 - Inspection


Check to make sure you got everything supplied by factory and there is no visible or concealed damage. In case of missing items, please contact customer service immediately and have the Product Serial # handy. (Product Serial # can be found at the back of the control valve, see below)





The items you will expect are:

- 1. Tank with Carbon Media loaded
- 2. Control Valve
- 3. Parts Kit











Step 2 – Installing Valve to the Tank

Select a Installation location and make sure there is access to 110V power outlet and drain line. Lube the bottom Valve Orings with the grease supplied, Attach the Upper Basket. Unscrew the spill cap. Carefully Slide the D-Tube inside the Valve and Screw the Valve inside the Tank such that the power cord doesnt get caught between the valve and the tank








Step 4 – Change Drain Line Flow Washer

- 1. Remove the red clip as shown
- 2. Pull the drain elbow
- **3.** Remove and Replace the washer as shown.

For 1 CF - use #5 (3.5 GPM) For 1.5 CF - use #6 (4.0 GPM)







Step 5 – Power the Valve and Master Program to Filter Configuration

Attach the Transformer cable to the valve and plug in the transformer to the 110V Power outlet. you will notice the two screens on right will alternate.

TIME 08:27 AM REMAIN GAL 1060



KEYPAD

1. Hold UP and DOWN button for 5 seconds and Adjust Valve Type to "CALENDAR CLOCK". PRESS SELECT

CALENDAR CLOCK

2. Adjust Regeneration Time. Press **UP** and **DOWN** key to quickly advance the hour and minuted. When desired time is displayed, press **SELECT** to Backwash

REG TIME 02:00 AM

3. Adjust Backwash Time to 10 Minutes. **UP** and **DOWN** key to quickly change the minutes. When desired minutes press **SELECT** to Brine

BACKWASH 10 MIN

4. Adjust Brine Time to 1 Minute. Press UP and DOWN key to quickly change the minutes. When desired minutes press SELECT to Rinse

BRINE 01 MIN

5. Adjust Rinse Time to 10 Minutes. Press UP and DOWN key to quickly change the minutes. When desired minutes press SELECT to Refill

RINSE 10 MIN

6. Adjust Refill Time to 0.0 Minutes. Press UP and DOWN key to quickly change the minutes. When desired minutes press SELECT to complete the programming

REFILL 0.0 MIN

Step 6 – Program the Valve

1. Press **SETTINGS** key to advance to **TIME OF DAY. TIME OF DAY** will flash.

TIME 08:27 AM

2. Press the UP or DOWN key to adjust the TIME OF DAY. Press & hold the UP or DOWN key to quickly advance the hour and minutes. When desired time is displayed press SELECT to advance to the REGEN DAYS setting. REGEN DAYS will flash.

3. Press SELECT to complete pro-gramming. Now you will notice that two screens below will alternate. Time and Reg Days

TIME 08:27 AM REMAIN DAYS 03

Follow the Instruction Manual to Complete the Installation of the Product

